



**Simply better.**

# OLD SALEM 1059 HARD RACING COPPER BRONZE NON-ANTIFOULING

**TECHNICAL BULLETIN 170 5/06**

- For dry sailed boats or boats stored in non-fouling fresh water.
- Can be buffed to give a high gloss, ultra smooth surface.
- Suitable for use on fiberglass, wood and steel hulls.
- Excellent for trailered boats.

## GENERAL DESCRIPTION

1959 Hard Racing Copper Bronze is recommended for use in fresh water on racing hulls, sailboats, runabouts or cruisers. It is a non-antifouling hard racing finish that can be buffed to give a high-gloss, ultra smooth surface. It can be used in saltwater for small, dry sailed boats which are not left in the water. When used above the waterline in saltwater, the 1959 Hard Racing Copper Bronze will oxidize to a green color if not overcoated with a clear sealing coat. 1959 Hard Racing Copper Bronze may be applied over most aged hard racing non-antifouling coatings. If the old paint type is unknown, sand a small area and apply a test patch of 1959 Hard Racing Copper Bronze to test its compatibility with the old paint. If the 1959 cracks or lifts the old paint, all the old paint will have to be removed. If nothing appears to happen when the 1959 is applied, let the test patch dry overnight, then scrape the 1959 to see if it is adhering to the old paint satisfactorily. If the adhesion looks good follow the recommendation for Previously Painted Surfaces.

## APPLICATION INFORMATION

1959 Hard Racing Copper Bronze is loaded with copper flake pigment. As a result of this there is a tendency for settling to occur, especially if the paint has been on the shelf for several months. It is necessary to thoroughly mix the paint before using. If possible shake the can of paint on a mechanical paint shaker. Before using check the sides and bottom of the can to make sure all the pigment has been mixed in. If mixing is going to be done with a wooden paddle or an electric drill mixer, pour off half of the liquid from the top of the can into another can and then properly mix in any settled pigment; then remix the two parts together thoroughly.

Adhere to all application instructions, precautions, conditions and limitations to obtain optimum performance. Refer to individual labels and tech sheets for detailed instructions when using associated products, etc. Do not thin 1959 Hard Racing Copper Bronze more than 5% (6.4 ounces per gallon) or inadequate paint film thickness will occur and premature erosion of the finish will be likely.

## SURFACE PREPARATION

Coating performance, in general, is proportional to the degree of surface preparation. Follow recommendations carefully, avoiding shortcuts. Inadequate preparation of surfaces will virtually assure inadequate coating performance.

## PHYSICAL DATA

VEHICLE TYPE.....Oleoresinous Varnish  
FINISH.....Glossy  
COLOR.....Bronze  
COMPONENTS....One  
CURING MECHANISM....Solvent Release Oxidation  
SOLIDS (theoretical)  
By weight.....63 ± 2%  
By volume....43 ± 2%  
COVERAGE.....800 sq. ft/gal.  
VOC....450 g/l (3.76 lbs/gal) as supplied  
FLASH POINT....106°F

## APPLICATION DATA

METHOD.....Brush, Roller, Airless or  
Conventional Spray  
NUMBER OF COATS....Two  
DRY FILM THICKNESS PER COAT.....  
0.75 - 1.0 mils  
WET FILM THICKNESS PER COAT....  
1.75 - 2.3 mils  
APPLICATION TEMP.....50° F. Min. / 90° F. Max.  
DRY TIME\*  
To Recoat To Launch  
90°F 8 hrs. 2 days  
70°F 16 hrs. 4 days  
50°F 36 hrs. 8 days

\*The above dry times are minimums.  
1959 may be recoated after the minimum  
time shown. There is no maximum launch  
time on 1959.

THINNER.....120 Brushing Thinner  
121 Spraying Thinner

## ASSOCIATED PRODUCTS

4700/4701 High Build Epoxy Primer  
6455 Metal Primer  
6627 Tie-Coat Primer  
6999 Sandless Primer  
120 Brushing Thinner  
121 Spraying Thinner  
95 Fiberglass Dewaxer

## SYSTEMS

The paint systems outlined below contain references to other Pettit products. Please read and understand the label and/or Technical Bulletin for these products as well to ensure that they are used properly. For further guidance, please contact your local Pettit salesman or the Pettit Customer Service Department at (800) 221-4466 between the hours of 8:30 a.m. and 4:30 p.m. EST. Previously Painted Surfaces: If the previous coating is in good condition, thoroughly sand with 80 grit production paper and wipe clean with a rag dampened with Pettit 120 Brushing Thinner to remove sanding residue. Apply two coats of 1959 Hard Racing Copper Bronze observing the proper dry times. If the previous coating is soft or in poor condition, remove to the bare surface by sanding or using Marine Grade Bottom Paint Remover 9050. Proceed with the appropriate bare system as described below. Old tin copolymer paints must be removed before applying 1959.

**Bare Fiberglass:** All bare fiberglass, regardless of age, must be thoroughly cleaned using 95 Fiberglass Dewaxer and clean lint-free rags. Several cleanings may be necessary to ensure complete removal of contaminants. Change rags frequently during the dewaxing/cleaning process to ensure complete removal of contaminants rather than merely smearing them on the surface. New boats must be scrubbed with a detergent and water solution and rinsed with fresh water prior to dewaxing. After the surface has been dewaxed, sand it thoroughly with 80 grit production paper and rewash the sanded surfaces with 95 Dewaxer or 120 Brushing Thinner to remove sanding residue. Apply one coat of Pettit Protect 4700/4701 High Build Epoxy Primer. When thoroughly dry, sand with 80 grit paper and wipe clean again. Apply two coats of 1959 Hard Racing Copper Bronze.

If sanding is prohibited, as with certain vinyl-ester gelcoats, or is otherwise impractical, make sure the surface has been completely and thoroughly dewaxed and cleaned with Pettit 95 Fiberglass Dewaxer. Then apply one, thin, continuous coat of Pettit 6999 Sandless Primer. Topcoat with two coats of 1959 carefully following the topcoating instructions on the Sandless Primer label.

**Bare Wood:** Sand the entire surface with 80 grit production paper and wipe clean with a rag dampened with Pettit 120 Brushing Thinner. Apply a coat of Pettit 6627 Tie Coat Primer thinned 25% with the 120 Brushing Thinner to penetrate and seal the wood. Fill any open seams with Pettit Seam Compound (7110 White or 7610 Mahogany) and allow to dry overnight. Apply two full coats of 1959 observing the proper dry times.

**Steel Hulls, Underwater Metal Parts and Keels:** For steel hulls and metal keels, wash the surface with Pettit 120 Brushing Thinner to remove any oil film or grease. The metal should be abraded with emery cloth to a bright texture. Remove all sanding residue by vacuuming or with clean, compressed air. Apply one, thin wet coat of Pettit 6455 Metal Primer; allow to dry at least two hours and then apply two coats of Pettit 6627 Tie Coat Primer followed by two coats of 1959 Hard Racing Copper Bronze.

**DO NOT USE THIS PRODUCT ON ALUMINUM HULLS OR OUTDRIVES.**